
We cannot take any responsibility for any damage caused by not using our genuine filter or part.

HOT&COLD WATER PURIFIER OPERATION MANUAL

WHP-4200/4200S WHP-4210/4210S WHP-4240/4240S WHP-4250/4250S




- Please read carefully and follow all guidelines to use safely and avoid equipment damage.
- The degrees of potential danger and equipment damage that could occur by improper use are divided into 3 types as per below.

Danger : If not observed, risk of serious injury or even death. Warning : If not observed, serious injury or property damage is possible. **Caution** : If not observed, minor injury or property damage could occur.

This warning sign is for highlighting potential risks caused by improper use. Please read carefully and follow all precautions.

Precautions for Power Supply




Please clean dust and all foreign **DANGER** substances off the plug before use.





Please disconnect plug from socket DANGER before replacing filter.

> % Failure to do so may cause fire or electric shock.




Precautions for Power Supply



DO NOT try to bend, tie or pull the DANGER power cord.

> % Failure to do so may cause fire or electric shock.





DO NOT disassemble or modify the

* Failure to do so may cause fire or electric shock.





Use a single socket for the unit.

* Do not plug multiple units into a single socket.





DO NOT touch socket with wet hands.

* Failure to do so may cause an electric shock



Precautions for Use



DO NOT install the unit in a high humidity area such as a bathroom, shower room or outdoors.


* Failure to do so may cause a fire or electric shock




DANGER bends.

Keep the inlet hose free from kinks or

* Failure to do so may result in water leakage or an electric shock



Precautions for Installation




Precautions for Use




DO NOT insert sharp implements such DANGER as a screwdriver into the unit.

> * Failure to do so may cause malfunction or electric shock.


> > :








% Failure to do so may cause the unit to malfunction.



DO NOT place heavy items on top of CAUTION the unit.

* This can cause the unit to malfunction.





Caution is advised when using hot water.





CAUTION Do not move the unit while in operation.

% Failure to do so may cause the unit to malfunction.





Please disconnect plug from socket DANGER before replacing filter.

> % Failure to do so may cause fire or electric shock.




Precautions for Use




Be careful not to use harmful or abrasive DANGER chemicals during the cleaning process.

> ※ This could lead to damage or discoloration of the unit.



When restarting after shutting off the power or moving the product, open the water WARNING supply valve, and use it only after dispensing at least 3 liters of cold/ambient/hot water.

> * Failure to do so may cause a fire hazard or water leakage.





MAKE SURE that the cold water tank lid is securely shut, before using. * Failure to do so can cause insects and/o foreign objects to enter the tank.



- * This appliance is not intended for use by persons(including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge of the product unless they have been given supervison or instruction concerning the use of the appliance by a person responsible for their saftey.
- % Children should not play with the appliance.
- % This appliance is not intended for use in household and similiar applications such as
 - staff kitchen areas in shops, offices and other working environments
 - farm houses and by clients in hotels, motels and other residential type environment
 - bed and breakfast type environment
 - catering and similar non-retail apllications



When discarding parts/filter and/or disposing the product entirely, please refer to all local guidelines * Failure to do so can cause environmental pollution.

	When i
CAUTION	∦ Failu

nstalling the product, always use genuine parts. ire to do so can cause water leakage and product damage.



When replacing filters, always use genuine filters.

* Failure to do so can cause poor performance and poor water quality.




DO NOT install the product in severe and extreme temperatures. * Failure to do so can cause overheating or freezing.

6


Parts identification

Model No. WHP-4200S / 4210S

Hot & Cold function




Model No. WHP-4200 / 4210




Parts identification

Model No. WHP-4240S / 4250S


Hot & Cold function



Model No. WHP-4240 / 4250



Filtration system




INTERIOR DIAGRAM

FILTRATION SYSTEM

DIVISION	1ST STEP	2ND STEP	3RD STEP	4TH STEP
Filter name	Sediment filter	Pre-carbon filter	Nanofact filter	Post-carbon block filter
Expected Repalcement	4 Months	8 Months	20 Months	12 Months
Water Supply Valve		nofact Post-carbon block filter	When usi must be f service ce	ibing/Float Valve, etc. are consumable require replacement approximately as. Failure to replace these parts can perty damage by water Leakage. In or replacing new filters, all filters lushed properly. Please contact local inter for proper filter flushing guidelir

Filtration system



INTERIOR DIAGRAM

FILTRATION SYSTEM

DIVISION	1ST STEP	2ND STEP	3RD STEP	4TH STEP
Filter name	Sediment filter	Pre-carbon filter	R/O membrane filter	Post-carbon block filter
Expected Repalcement	4 Months	8 Months	24 Months	12 Months
Water Inlet Water Sedim filte	Pre-carbon filter	Restrictor		ubing/Float Valve, etc. are consumable require replacement approximately aras. Failure to replace these parts can operty damage by water leakage. In gor replacing new filters, all filters lushed properly. Please contact local anter for proper filter flushing guidelin



Power saving by ECO (Light sensor) function

The ECO sensor automatically stops water heating and save energy by sensing when the office lights are off and therefore the office is empty.

Continuous water dispensing function

By this function, you can conveniently dispense a large amount of water continuously.

Convenient for household use

Specially designed for household use by supplying purified water of 10 liters per day for a family.

Direct connection to the water supply

It can supply water conveniently and at an affordable price.

Thorough filtration system

- 1st Step. Sediment Filter (removes contaminants)
- 2nd Step. Pre-carbon Filter (removes residual chlorine)
- 3rd Step. Nanofact Filter(WHP-4200/WHP-4200S),

R/O membrane Filter(WHP-4210S/WHP-4210S)

- 4th Step. Post-carbon Filter (removes residual toxic gases and odor)

Fresh water supply

4~12°C of cold water and 70~90°C of hot water are available at any time.

Power saving function

It is possible to switch off either the hot or cold temperature functions when not in use, thus making additional energy savings.

Hot water safety features

Anti-overheating feature of hot tank (by manual reset type of bi-metal) and automatic temperature control function(by automatic reset type of bi-metal) helps prevent overheating tank.

Water level control function

Automatic water level control function ensures durability of the filters and unit.

Efficient and useful

Easy to install and convenient to use.

Directly connects to sink faucet (Option)

It is possible to connect directly onto the sink faucet (option) in order to use purified filter for cooking and all other uses.

How to use

% For your safety and proper use of the product, please read and understand the following before use

1. Plug the power cord.


* Before plugging, please check if the voltage rate is matching.



2. Open the water supply valve.

% If water supply valve is closed, the water purifier doesn't work.

(Except in case of leaving the system unused for an extended period, leave the valve open.)




1) How to use ECO function


- 1) Turn on the ECO switch at the back of the unit.
- 2 When the ECO switch is turned on, the hot water light shows orange.
- ③ When the ECO function is in operating, the hot water lamp will change to on green.
 - ** The ECO sensor automatically stops water heating to save energy costs when it detects the office lights have been turned off.

2) How to use hot water function

- ① Turn on the hot water switch at the back of the unit.
- 2 When the hot water switch is turned on, the hot water lamp is on red.
- ③ Please allow approximately 20 minutes for the hot water to heat up after the hot water switch is turned on.
- ④ After hot water function is activated, the hot water temperature controller will automatically adjust the hot water temperature.



How to use



% After the installation of the product, please drain out 20 liters of water.
% When not using the product for a prolonged period, drain 1~2 liters of water before use again.

UV sterilization system

WHP-4210/WHP-4210S/WHP-4250/WHP-4250S


1) UV LED sterilization is operated initially when the electronic power cord is connected.

- There is no on/off switch for UV LED operation and it is operated automatically.
- The UV LED function may deteriorate after 5 or more years of use.
- During operation of UV LED, the UV LED lamp flickers on and off.


2) STERILIZATION CYCLE: 2 hours per day

* Please make sure to unplug power cord when opening the tank lid.

- Failure to do so can cause exposure to the light of the UV LED in the cold tank.



Filter replacement



Filter replacement

- Before replacing any filters, please make sure to pull the power cord out and close the water supply valve.
 - Black carbon dust powder may come out after initial installation or replacement of filters. (It is simply the fine powder of activated carbon that improves the taste of water and does not have any affect on the human body.)
 - When using the product for the first time or after replacing the filters, please use the product after performing a "water flushing' of at least 10l and until the water is running clear. (What is water flushing? Upon first use of the filter, this is the process to remove any alien substances such as dust from the water path by passing water through them.)
 - It's recommended to clean the inside of inside of the water tank regularly to ensure maximum hygiene.



- According to the filter replacement cycle, replace filters regularly.
- If filters are not regularly replaced, it could degrade the water quality.
- The filter replacement cycle may vary depending on feed water quality and consumption.
- Even if your water consumption is low, following regular filter replacement cycle is recommended.
- The effective filtration amount means the minimum processing capacity at which contaminants can be effectively removed without cleaning, regenerating, or replacing the filter.
- \bullet Recommended water consumption : 10 ℓ / a day (Based on a family of four.)

Troubleshooting Guide

* Please check the following prior to contacting the After Sales Center.

Problem	Cause	Solution
Insufficiently	Low power supply	Check voltage rate.
heated water	Hot water switch off	Check to make sure that the Hot water switch is turned on.
Insufficiently	Low power supply	Check voltage rate.
chilled water	Cold water switch off	Check to make sure that the Cold water switch is turned on.
	Filter change needed	Check filter change schedule and contact local customer service center.
No water comes out	Water supply shut off	Unplug the power cord and plug back in to restart the system.
	Tubing Blockage	Check the tubing to make sure that it is not bent or kinked preventing water flow.
No heating	Temperature Controller Shut Down/ Heater Malfuntion	Turn off Hot water switch and contact local customer service center. (Temp. Controller automatically shuts off power supply to Hot water tank to prevent overheating.)
Abnormal hot & cold water temperatures	Heavy water Consumption	High volume of water consumption will cause the water temperatures to fluctuate. Please allow 5~10 minutes for the temperatures to recover.
Noisy sound	Compressor Operating sound	When the compressor is activated, it is normal to hear sounds of the refrigerant flowing through the system.

Troubleshooting Guide

% Please check the following prior to contacting the After Sales Center

Problem	Cause	Solution
Decreased water	Filter need to be replaced	Replace filters.
production	Low pressure feed water	If low pressure water is supplied to unit, lower amount of filtered water is produced.
Water leakage	Low power supply	Close the water supply valve and contact customer service center.
	Life of post carbon block filter expired	Replace the post carbon block filter and use the product after performing 'Water Flushing' at least 10ℓ until the water runs clear from the faucet.
Unpleasant water taste or odors	Cold tank is not cleaned	Empty the residual water in the cold tank and clean.
	Water has been stored in an inappropriate condition for a prolonged period	Replace all the filters and clean cold tank.
Particles in water	It may be bubbles when dispensing water	After 10 minutes, if the particles remain, contact customer seviece center.

% If a problem occurs, contact a customer service center and get filter replacement or repair service.

% We can not take reponsibility for any damage caused by replacing filters by third party who is not our.

Cleaning method

COLD TANK AND HOT TANK CLEANING

- 1. Shut off water supply valve and unplug power cord.
- 2. Drain all water in the cold tank by dispensing it from the cold water nozzle.
- 3-1). Stand Type [WHP-4200] Remove the lower panel to access drain valve and open drain valve to drain water completely.
 (Please be careful when draining out the Hot Water as it may cause severe burns.)
- 3-2). Countertop Type [WHP-4200S] Remove side panel to access drain valve and open drain valve to drain water completely. (Please be careful when draining out the Hot Water as it may cause severe burns.)
- 4. Unscrew the two screws on the left and right at the back of the product and remove the top cover. Then remove the Cold Tank Cover. (Please be careful not to damage the rubber packing when removing the Cold Tank Cover. Also, the Cold Tank is made out of stainless steel. Please use caution to prevent injury.)
- 5. Clean the cold tank by flushing it out with water. (Make sure to close the drain valve when done.)
- 6. Drain out the cleaning water completely by pulling the cold lever to forward
- 7. Open Water Supply Valve and check for any water leakage until the Cold Tank is completely full. Then, re-assemble the top cover.
- 8. Please monitor the product for a day to check for leakage.
- * Please contact local customer service center for cleaning service if the product has not been used for an extended period of time.
- * CAUTION: Please contact local customer service center. DO NOT attempt to do by yourself.

Cleaning Cylcle

Cleaning	Cycle	Method
Exterior	Once a week	Clean the exterior with water-soaked, soft cloth. (Never use harsh chemicals to clean the unit.)
Drip tray	Frequently	Frequently clean the drip tray with a neutral detergent.
Fitting/ Tubing	At least every 2 years	Change the fitting and tubing once every two years when replacing filters.
Water faucet	Daily	Detach the hygiene guard by turning it counterclockwise and rinse in running water. When you attach the hygiene guard again, fix it firmly, to prevent risk of leaking. (If there is damage on the hygiene guard, please replace.)

Specifications

Product Name	HOT & COLD WATER PURIFIER	
Model No.	WHP-4200 / WHP-4210 WHP-4240 / WHP-4250	WHP-4200S / WHP-4210S WHP-4240S / WHP-4250S
Power Supply	AC 120V, 220-2	240V, 50/60Hz
External dimensions	260(W)*370(D)*1100(H)mm	260(W)*460(D)*495(H)mm
Recommended water consumption	10ℓ / a day (Based	d on four people)
Cold water capacity	Abt. 1.8ℓ	Abt. 1.8ℓ
Cold water temperature	about 4	°C-12°C
Motor power consumption	0.6A	
Heater power consumption	430W – 510W	
Hot water capacity	Abt. 1.8ℓ	Abt. 1.4ℓ
Hot water temperature	70°C-	90°C
	Working pressu	ure : 98-490kPa
Service condition	Working tempe	erature : 5~35°C
Service condition	Usable feed w	vater : Potable
	Indoor use only (H	lousehold / Office)

FILTRATION SYSTEM

	Model No.	WHP-4200/WHP-4200S WHP-4210/WHP-4210S	WHP-4240/WHP-4240S WHP-4250/WHP-4250S
	Sediment filter (P.P)	0	0
FILTRATION	Pre-carbon filter (Activated carbon)	0	0
SYSTEM	Nanofact filter (Cellulose, Activated carbon)	0	
	R/O membrane filter (Polyamide)		0
	Post-carbon block filter (Activated carbon)	0	0

Warranty Card

וחסחם	ICT			
PRODI	JCI	VVAR	KAI	NIY

සම අව හැක අව හ

Date of Manufacture Date of Purchase Year Month Day Customer's Name	Product	Model	 □ WHP-4200/4200S □ WHP-4210/4210S □ WHP-4240/4240S □ WHP-4250/4250S
Customer's Name Dealer's Name /ARRANTY GUIDE . The warranty period is 12 months from date of purchase In the following circumstances, the product will be repaired at cost a) After expiry of free warranty period. b) Malfunction caused by careless or abnormal use. c) Malfunction caused by natural disaster.		Date of Manufacture	
Dealer's Name /ARRANTY GUIDE The warranty period is 12 months from date of purchase. In the following circumstances, the product will be repaired at cost a) After expiry of free warranty period. b) Malfunction caused by careless or abnormal use. c) Malfunction caused by natural disaster.	Date of Purchase	Year Mont	h Day
ARRANTY GUIDE The warranty period is 12 months from date of purchase. In the following circumstances, the product will be repaired at cost a) After expiry of free warranty period. b) Malfunction caused by careless or abnormal use. c) Malfunction caused by natural disaster.	Customer's Name		
The warranty period is 12 months from date of purchase. In the following circumstances, the product will be repaired at cost a) After expiry of free warranty period. b) Malfunction caused by careless or abnormal use. c) Malfunction caused by natural disaster.	Dealer's Name		
	a) After expiry of freeb) Malfunction causec) Malfunction cause	e warranty period. ed by careless or abnor ed by natural disaster.	·







