AIR PURIFIER OPERATION MANUAL

MODEL: WHA-200



CONTENTS

| • Features 2 |
|-------------------------------------|
| Name of each part 3 |
| • Precautions4~7 |
| Installation& Product Information 8 |
| Touch control buttons |
| • Maintenance 10~13 |
| Solutions to common problems 14 |
| Product specification15 |
| • Warranty 16 |
| |

To keep the best working condition and guarantee long life, read this manual carefully before you operate this equipment.






Manufacturer



FEATURES

NAME OF EACH PART

PURIFICATION SYSTEM



1) Pre filter

➤ Traps larger particles such as dust, human hair and pet dander.(Washable)

2 Carbon filter

Traps fine dust, particles, smoke, a wide variety of gases, odors and formaldehyde to clean the air, particularly of unpleasant odors.


③ Perfect filter

▶ Traps unpleasant odors and have anti bacterial effect,

4 Hepa filter

➤ Traps 99.9% of microscopic particles (up to 0.3 microns), including tobacco smoke, and common allergens like pollen, mold spores and household dust.

MOOD LIGHTING AND POLLUTION INDICATING SYSTEM



While being operated in automatic mode, dust sensor detects the air pollution status and shows the condition by four colors of pollution indicator lamp.




If you touch the Mood lamp sensor, Pollution indicator lamp will be turned into white mood light.

ONCE (Low brightness) ► TWICE (Medium brightness) ► 3TIMES (High brightness) ► 4TIMES (Pollution indicator lamp ON)

Without turning on the power, you can use it only for mood lamp by just touching the Mood lamp sensor.


ONCE (High brightness) ► TWICE (Medium brightness) ► 3TIMES (High brightness) ► 4TIMES (Mood lamp OFF)



FRONT

COVER

<TOP SIDE>



CARBON

FILTER

FILTER



ODOR SENSOR (OPTIONAL)

HEPA FILTER

PERFECT

PRECAUTIONS

PRECAUTIONS

Read carefully following precautions to prevent unpredictable dangers and damages.



Follow these instructions to avoid any risk of personal injury, property damage, electrical shocks or fire hazards.



Failure to follow the safety instruction can lead to personal injury or property damage.

PRECATIONS FOR INSTALLATION



Do not operate the unit near CAUTIONS flammable materials. NOTICE (such as spray, oil, gas etc.)

▶It may cause a fire or explosion.





Do not install the unit at a humid CAUTIONS place such as bath house, NOTICE shower room or swimming pool.

▶It may cause an electric shock or fire.





Do not place flammable substances nearby the unit.

▶It may cause a fire.



Place the unit on a level and hard floor.

►It may cause a malfunction or deformation of exterior.

PRECATIONS FOR USE



Do not insert a plug in a loose socket.

▶It may cause an electric shock or fire.





Check the voltage rating & type of socket.

▶ It may cause an electric shock or fire.





Do not replace or modify the plug.

▶ If the power cord/plug is damaged, it must be replaced by the manufacturer or a qualified technician



Do not touch the plug with wet hands. ▶It may cause an electric shock.





Do not unplug the unit by pulling out its power cord.

NOTICE It may cause electric shock or fire



Do not install the unit under the power outlet. CAUTIONS

►It may cause fire.



Do not severely bend the power cord or put heavy object on it. NOTICE ►It may cause a fire.

PRECAUTIONS

PRECAUTIONS

PRECAUTIONS FOR USE



Do not disconnect the power cord during operation.

▶It may cause a malfunction or fire.





Do not touch the inner part with wet hands.


►It may cause an electric shock





Do not operate the unit without filters.

►It may cause an electric shock





Do not spray or pour water to the

▶It may cause a malfunction or fire.





Do not insert anything into the air inlet or outlet.

► Especially attention to children. It may cause burns, electric shock and failure.





Do not allow children to play on or near the unit.

►It may cause a malfunction or deformation of exterior





Do not use the unit in a place that has much of toxic gases.





Do not use the unit in greasy or dusty places such as restaurants, kitchens or construction site.



PRECACUTIONS FOR USE



Do not spray pesticide or flammable Do not s liquids.

▶It may cause a malfunction.





Do not place clothes or towels on Do not place clothes of towers top of the unit while operating.

►It may block air inlet and cause a malfunction.





Do not strike or knock the unit over.


▶ It may cause a malfunction





Stop using the unit if any irregular noise or smoke occurs.

Pull out the plug and then call customer service center.





Do not put the heavy stuff on top of Do not pu

▶It may cause a malfunction or deformation of exterior.





Do not disassemble, repair or modify by yourself.


▶It may cause a malfunction, electric shock or fire.





Do not use the unit for any purpose other than indoor air purification

▶If used in the kitchen instead of ventilator. the filter replacement cycle will be shorten.





Do not use the unit in too cold or hot place.

▶ Optimum temperature for use is between 5°C and 30°C





INSTALLATION

TOUCH CONTROL BUTTONS

Install the unit indoor and avoid direct sunlight.

▶ It may cause a malfunction.

Do not install the unit in humid or unventilated place.


▶ It may cause an electric shock and fire.

Place the unit at least 30cm away from TV, Radio or any other electronic goods.

▶ It may cause a malfunction by electromagnetic interference.

Place the unit on a level and hard floor.

▶ It may cause noise or vibration. Place the unit at least 10cm away from the wall,



PRODUCT INFORMATION

Do not operate the unit without filters. When it has unpleasant odors, please replace filters.

- ► It doesn't have air purifying effect, without filters.
- ▶ Polluted filters degrade Air purification efficiency of the unit. If filters get dirty or have bad smells, please replace them.

Do not use the Air purifier to reduce odors during cooking.

- ▶ Bad odors will shorten filter replacement cycle.
- ▶ If bad smell comes from the unit during operation. Please replace the Perfect filter & HEPA filter.

While using the Air purifier, please close the window and door.

▶ If the windows and doors are open, the air purifier will be less effective.

TOUCH CONTROL BUTTONS











SLEEP MODE

TIMER

POWER (LOCK BUTTON)

FAN SPEED

(AUTOMATIC OPERATION) (FILTER REPLACEMENT INDICATOR)

| (I). | POWER (LOCK BUTTON) | Power ON and OFF / 'LOCK' setting |
|------|---|---|
| (T) | FAN SPEED (AUTO) | Fan speed control (LOW, MED, HIGH, TURBO, AUTO) |
| | CLUSTER IONIZER (FILTER REPLACEMENT INDICATOR) | IONIZER ON/OFF(Indicating Filter replacement cycle) |
| | TIMER | OFF Timer setting |
| 0 | SLEEP MODE | SLEEP MODE operation setting |

HOW TO CONTROL

POWER (lock button)

- If touching the power button, the operation will start with 'DING' sound and low fan speed.
- If touching the power button more than 3 sec, the control buttons will be locked. (Only one lamp on the power button is turned on.)
- If touching again the power button more than 3 sec, the control buttons will be unlocked.

FAN SPEED (AUTOMATIC OPERATION)

- · Each time the button is touched, the Fan speed changes.
- · Location of LED lamps around the button will be changed according to fan speed.



(ONCE)





(3 Times)



AUTOMATC OPERATION FUNCTION (3 LED LAMPS AROUND FAN SPEED BUTTON WILL LIGHT UP)

- · When the auto mode is set, the dust sensor controls fan speed depending on the air quality.
- · According to the air condition, the color of pollution indicator lamp will be changed.



TIMER

• Each time the button is touched, the OFF TIMER is set after 2.4 or 8 hours.

SLEEP MODE

• The lowest fan speed & brightness of lamps will be set.

CLUSTER IONIZER

· Cluster ionizer cleans the air by sending molecular particles into the room. Those particles, also known as ions, attach to oxygen in the air to create a negative charge.

FILTER REPLACEMENT INDICATOR

- When it's time to change HEPA filter, 3LED lamps around cluster ionizer button is blinked.
- · After filter replacement, touch the button for more than 3 sec to reset.

MAINTENANCE

MAINTENANCE

BEFORE FILTER REPLACEMENT

When the filter replacement cycle indicator is blinking, please replace the filter set.


The filter replacement cycle is about one year.

* The filter replacement cycle may vary depending on use environment.

The filter replacement indication is on the basis of HEPA filter's lifespan. Please replace the other filters referring to page13.


· Be sure to use genuine filters.






- Please be sure to disconnect the power plug before replacing filter.
- Please take off plastic packaging of filter set.
 If don't, it may cause fire or deformation of product.
- After replacing filters, please touch the cluster ionizer button for more than 3 sec until it makes 'DING' sound to reset,


HOW TO REPLACE FILTER






Hold grip of Pre-filter and pull it out.









CAUTION • BE SURE TO USE GENUINE FILTERS.


MAINTENANCE

MAINTENANCE

DUST SENSOR CLEANING










- Do not clean the sensor with volatile substances other than water.
- If Dust sensor still has the foreign substance, the air pollution indicator lamp won't be changed. So, please clean the sensor again.
- Clean the sensor every 6month. But the cleaning cycle could vary depending on the use environment.

FILTER CLEANING & REPLACEMENT CYCLE

| Kind of filter | Replacement Cycle | Cleaning Cycle | Cleaning method |
|----------------|-------------------|---|-----------------|
| PRE FILTER | semi-permanent | About 1 month Use the Vacuum Cleaner or brush. If heavily polluted, please wash with a neutral detergent. | |
| HEPA FILTER | About 12Month | | |
| CARBON FILTER | About 8Month | DO NOT WASH | |
| PERFECT FILTER | About 4Month | | |

EXTERIOR CLEANING

- Clean the exterior with a dry cloth
- clean the front cover with a vacuum cleaner or dust brush about once a month,





- Turn off the Air purifier and pull the plug out before performing any maintenance.
- Do not use Benzene, Alcohol, or any other Volatile substances.

(12)

SOLUTIONS TO COMMON PROBLEMS

PRODUCT SPECIFICATIONS

Check the followings before asking service center.

| State | Check | Solution | |
|---|--|---|--|
| The unit does not oprerate | Is the plug correctly inserted? | Correctly insert the plug into the socket. | |
| not oprerate | Check power outage | Use the Air purifier after checking power supply. | |
| Automatic mode | Is the plug correctly inserted? | Collectly insert the plug. Then set the Automatic mode again. | |
| does not work | Check if the Auto mode is set. | Set the Automatic mode. | |
| | | Clean the dust sensor. If still on RED light, please call customer service center. | |
| Strong Noise and vibration | Is the unit installed on uneven floor? | Install the Air purifier on even floor. | |
| Plug& outlet is getting hot • Check the power plug. | | Correctly insert the plug into the socket. | |
| Strange odors | Is the unit used in a smelly or smoky place? | Clean the inlet AIR VENT and PRE-FILTER. Replace The Perfect filter. | |
| The air is not cleaned. The air flow is weaken | Check the filter replacement indicator. | Clean the Pre-filter. Replace the HEPA filter. | |
| Strange indication | Check if the LED lamps around the fan speed button flickers with 'Ring-Ring'sound. | It has problem. Call customer service center. | |
| Strange sounds | • Check noise | While the cluster ionizer is being operated, it could make some noise. | |

| Product Name | Air Purifier |
|---------------------------------------|--------------|
| Model No. | WHA-200 |
| Rated Voltage | 220V / 60Hz |
| Power Consumption | 34W |
| Air Purifying Available Area | 34 m² |
| Dimension 430(W) x 280(D) X 642(H) mm | |
| Weight 6.6kg | |

PRODUCT WARRANTY

MEMO



PRODUCT WARRANTY

| Product | Model | | WHA-200 |
|------------------|-------------------|------|---------|
| | Date of Manufanto | ire | |
| Date of Purchase | Year M | onth | Day |
| Customer's Name | | | |
| Dealer's Name | | | |

WARRANTY GUIDE

- 1. The warranty period is 12 months from date of purchase.
- 2. In following case, the product will be repaired at cost.
 - a) After expiry of free warranty period.
 - b) Malfunction of caused by careless or abnormal use.
 - c) Malfunction of caused by natural disaster.
 - d) In case this manual has been lost.



Head Office & Factory

161, Yanggok-ro, Yangchon-eup, Gimpo-si, Gyeonggi-do, Korea

Tel: 82-31-987-7101 Fax: 82-31-989-6109

